



DI-1110

8-Channel USB Data Acquisition Starter Kit

User's Manual

Manual Revision C

Copyright © 2020 by DATAQ Instruments, Inc. The Information contained herein is the exclusive property of DATAQ Instruments, Inc., except as otherwise indicated and shall not be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any human or computer language, in any form or by any means, electronic, mechanical, magnetic, optical, chemical, manual, or otherwise without expressed written authorization from the company. The distribution of this material outside the company may occur only as authorized by the company in writing.

DATAQ Instruments' hardware and software products are not designed to be used in the diagnosis and treatment of humans, nor are they to be used as critical components in any life-support systems whose failure to perform can reasonably be expected to cause significant injury to humans.

DATAQ, the DATAQ logo, and WINDAQ are registered trademarks of DATAQ Instruments, Inc. All rights reserved.



DATAQ Instruments, Inc.
241 Springside Drive
Akron, Ohio 44333 U.S.A.
Telephone: 330-668-1444
Fax: 330-666-5434

Designed and manufactured in the
United States of America

Warranty and Service Policy

Product Warranty

DATAQ Instruments, Inc. warrants that this hardware will be free from defects in materials and workmanship under normal use and service for a period of 90 days from the date of shipment. DATAQ Instruments' obligations under this warranty shall not arise until the defective material is shipped freight prepaid to DATAQ Instruments. The only responsibility of DATAQ Instruments under this warranty is to repair or replace, at its discretion and on a free of charge basis, the defective material.

This warranty does not extend to products that have been repaired or altered by persons other than DATAQ Instruments employees, or products that have been subjected to misuse, neglect, improper installation, or accident.

DATAQ Instruments shall have no liability for incidental or consequential damages of any kind arising out of the sale, installation, or use of its products.

Service Policy

1. All products returned to DATAQ Instruments for service, regardless of warranty status, must be on a freight-prepaid basis.
2. DATAQ Instruments will repair or replace any defective product within 5 days of its receipt.
3. For in-warranty repairs, DATAQ Instruments will return repaired items to the buyer freight prepaid. Out of warranty repairs will be returned with freight prepaid and added to the service invoice.

Table of Contents

Warranty and Service Policy	iii
1. Introduction	1
Features	1
Analog Inputs	1
Digital Inputs	1
Software	1
WinDaq Dashboard	2
WinDaq® Recording and Playback Software	2
Help	2
2. Specifications	3
3. Installation	5
Install WinDaq Software	5
Connect the Instrument to Your Computer	6
4. Controls, Indicators, and Connections	7
Mini-B USB Connection	7
Screw Terminals	7
DI-1110 Signal Connections	8
Connecting Signal Leads	8
Analog Inputs	9
Digital Ports	9
WinDaq Remote Events (Evt/D0)	10
WinDaq Remote Storage (Rcrd/D1)	12
WinDaq Rate (Rate/D2)	12
WinDaq Counter (Cnt/D3)	14
General Purpose Digital Inputs	16
General Purpose Digital Outputs	17
4-20mA Current Loop Measurements	18
LED Indicator	19
5. Unlock WinDaq	21
6. Dimensional Drawing	23

1. Introduction

This manual contains information designed to familiarize you with the features and functions of the DI-1110 USB data acquisition starter kit. These high-end Starter kits contain features and functionality normally reserved for more expensive data acquisition systems.

Features

The **DI-1110** data acquisition instrument is a portable data recording module that communicates through your computer's USB port. Power is derived from the interface port so no external power is required. Features include:

- 4 or 8 fixed differential analog inputs protected to $\pm 100V$ (transient).*
- $\pm 10V$ full scale measurement range.
- 12-bit analog-to-digital resolution.
- 7 digital ports* protected to +25V: Two dedicated for WINDAQ remote control operations; One dedicated to WINDAQ rate measurements; and One dedicated to WINDAQ counter measurements.
- Up to 160 kHz maximum throughput sampling rate.
- A push-button to tag remote events in WINDAQ software.
- LED indication for easy notification of system status.
- Free WinDaq/Lite data acquisition recording software.
- Included .Net Class supports programming the DI-1110 under any .Net programming language.
- Fully documented instrument protocol for programming the device in operating systems other than Windows.

* WinDaq/Unlock required to record more than four total channels when using WinDaq software.

Analog Inputs

The **DI-1110** features eight differential channel inputs (WinDaq/Unlock required to record more than four total channels when using WinDaq software) located on a single sixteen-position screw terminal block for easy connection and operation (other terminals used for digital I/O or reserved). Note: The DI-1110 does not support Gain.

Utilize the functionality of WINDAQ software to experience all the features encased in these small, inexpensive instruments.

Digital Inputs

The DI-1110 contains seven digital ports (WinDaq/Unlock required to record more than four total channels when using WinDaq software), which may be used as a general-purpose digital inputs or for a specific function as designated on the device. Digital port D0 is reserved for WinDaq Events; Digital port D1 is reserved for WinDaq remote Start/Stop; Digital port D2 is reserved for rate measurements; Digital port D3 is reserved for counts; Please Note: Digital outputs are not supported in WinDaq software. Each port may be configured as a switch using third-party software.

Software

All software required to record and playback waveforms is included with the purchase of any DI-1110 data acquisition starter kit via download.

WinDaq Dashboard

The WinDaq Dashboard utility allows you to start WinDaq software with your Dataq devices. Units available for synchronized recording using ChannelStretch™ are shown in compatible blocks of devices (the DI-1110 does not support ChannelStretch or stand-alone data logging).

WINDAQ® Recording and Playback Software

WINDAQ Acquisition and WINDAQ Waveform Browser allow you to record and playback data acquired through your instrument. WINDAQ software is an invaluable resource to record and analyze your data and is available for free from our web site (www.dataq.com).

WINDAQ Acquisition software can be used to record waveforms directly and continuously to disk while monitoring a real time display of the waveforms on-screen. It operates, displays, and records waveform signals in real time at the full sample rate of the DI-1110.

WINDAQ Waveform Browser playback software (also known as “WWB”) offers an easy way to review and analyze acquired waveforms. A built-in data file translator allows the user to display multiple waveforms acquired by WINDAQ Acquisition software or any of a wide range of data acquisition packages. The software’s disk-streaming design allows data files of any length to be graphically displayed rapidly, in normal or reverse time directions. Seven standard cursor-based measurements, frequency domain, and statistical analysis functions help simplify waveform analysis and interpretation. WINDAQ Waveform Browser is free and installed when installing WINDAQ Software.

Help

All WINDAQ software utilizes context-sensitive help. Help may be accessed through the Help menu or by pressing the F1 key with any pull-down menu item selected. This will take you directly to the Help topic most relevant to that particular function or feature. Help topics discuss in detail each function available in the software.

2. Specifications

Analog Inputs

Number of Channels:	8
Channel Configuration:	Differential
Full Scale Range:	± 10 V
Input impedance:	1M Ω
Absolute accuracy: @ 25°C, excluding common mode error	± 12.5 mV @ 25°C
Absolute maximum input without damage:	± 75 V peak, continuous ± 100 V peak, one minute or less
System noise:	7.8 mV rms
Max common mode voltage:	± 10 V
Common mode rejection ratio:	40 dB (dc - 60 Hz)
Channel-to-channel crosstalk rejection:	-80 dB

Digital Ports

Number of Ports:	7
Type:	MOSFET switch
Configuration:	Programmable as digital input or switch

Programmed as a Switch

Maximum drain voltage:	25 V
Maximum sink current:	100 mA

Count/Rate/Inputs

Internal pull-up value:	4.7 k Ω
Input high voltage threshold:	2.4V
Input low voltage threshold:	0.8V
Terminal count:	65,535
Maximum rate frequency:	50 KHz with one enabled channel, 20 KHz with 2-4 enabled channels, 10 KHz with 5-8 enabled channels, else 5 KHz.
Minimum rate frequency:	0.5Hz
Maximum count frequency:	50 kHz
Absolute maximum applied voltage (V):	+25V

Reserved Digital Inputs

D0:	WINDAQ remote events
D1:	WINDAQ remote start/stop
D2:	Rate input
D3:	Count input

ADC Characteristics

Resolution:	12-bit Above zero ADC counts: 2,047 Below zero ADC counts: 2,048
Voltage resolution (excluding noise):	4.86 mV
4-20 mA resolution (excluding noise):	818 adc counts with 250Ω shunt
Max. sample throughput rate:	160 kHz
Min. sample throughput rate:	Hardware only: 20 Hz WinDaq software: 2.2 samples per hour
Sample rate timing accuracy:	50 ppm

Indicators and Connections

Interface:	USB 2.0 (mini-B style connector)
Indicator light:	3 LEDs; Power, Active, Event
Input connections:	Two 16-position screw terminal strips

Power

Power Consumption:	<1.0 Watt, via USB interface
--------------------	------------------------------

Environmental

Operating Temperature:	0°C to 50°C (32°F to 122°F)
Operating Humidity:	0 to 90% non-condensing
Storage Temperature:	-20°C to 60°C (-4°F to 140°F)
Storage Humidity:	0 to 90% non-condensing

Physical Characteristics

Enclosure:	Polycarbonate ABS, 0.080 inch thickness
Mounting:	Desktop; bulkhead
Dimensions:	2.625D × 5.5W × 1.53H in. (6.67D × 13.97W × 3.89H cm.)
Weight:	5.7 oz. (162 grams)

Software Support

WINDAQ software:	OS support: Check online at http://www.dataq.com/products/windaq/windows-compatibility/
Programming:	DATAQ .NET Class, Instrument protocol, ActiveX Control

3. Installation

The following items are included with each DI-1110 USB Data Acquisition System. Verify that you have the following:

- A DI-1110 USB data acquisition instrument.
- 6-foot USB cable.
- A DATAQ Instruments screwdriver for signal lead connections.

If an item is missing or damaged, call DATAQ Instruments at 330-668-1444. We will guide you through the appropriate steps for replacing missing or damaged items. Save the original packing material in the unlikely event that your unit must, for any reason, be sent back to DATAQ Instruments.

Install WINDAQ Software

All software for the DI-1110 can be installed via a downloadable executable directly from the DATAQ Instruments web site. No CD is shipped with the device. You may burn the executable onto a CD or flash drive to transport the software to a computer with no internet connection.

1. Disconnect all DATAQ Instruments USB devices from your Computer.



2. Download software at run.dataq.com.
3. Save the executable (Dataq Software Suite Web Setup.exe) to your local hard drive.
4. Double-click on the executable to extract the program and begin software installation.
5. Follow the on-screen prompts and enter all required information.

6. Software installation is complete - you will now see a “Successful Installation” box - click **OK** to exit WINDAQ Installation.


You can now plug the device(s) into your PC. Click on the “WinDaq Dashboard” shortcut to access WINDAQ software.

Connect the Instrument to Your Computer

DI-1110 instruments can be connected to your computer’s USB port using the provided USB cable. No external power is required. Connect one end of the communications cable to the instrument port and the other to your PC’s port.

***Note:** Use a powered USB hub or a USB port on your PC. Non-powered USB hubs may not have sufficient power to run the instrument.*

4. Controls, Indicators, and Connections



Please note: The SD card slot is not used in the DI-1110. Allowing foreign materials to enter the device through the SD card slot may result in damage to the instrument.

Mini-B USB Connection

Use the supplied USB cable to connect and power the instrument through your computer's USB port.

Screw Terminals

All input signal connections are made to the 16-port screw terminals. Each terminal is labeled on the instrument case.

⚠ CAUTION ⚠


Do not touch the input terminals after signal cables are connected to the system under test, since it will cause an electric shock.

To avoid ESD damage in handling the device, take the following precautions:

Ground yourself with a grounding strap or by touching a grounded object before and during your handling of the instrument.

DI-1110 Signal Connections

Refer to the following for screw terminal port identification.



Ch#: Analog channels 1-8 (± 10 Volts Full Scale Fixed, ± 100 V max.)

D#: Digital port (0-6). Can also be used for specific WINDAQ functions (25 Vmax).

Evnt/D0 — WINDAQ Remote Event Marker (or general-purpose)

Rcrd/D1 — WINDAQ Remote Start/Stop (or general-purpose)

Rate/D2 — Rate Input (or general-purpose)

Cnt/D3 — Counter Input (or general-purpose)

D4 to D6 — General-purpose digital ports


+5V: +5V out. Max current = 100mA.

GnD: Ground.

Connecting Signal Leads

Connect signal leads to the DI-1110:


1. Insert the stripped end of a signal lead into the desired terminal directly under the screw.
2. Tighten the pressure flap by rotating the screw clockwise with a small screwdriver. Make sure that the pressure flap tightens only against the signal wire and not the wire insulation. Do not over-tighten.
3. Tug gently on the signal lead to ensure that it is firmly secured.




When an input signal is connected and WINDAQ Acquisition software is run, WINDAQ's real time display immediately reveals the input waveform on your computer's monitor.

Analog Inputs

Eight differential analog inputs* measure ± 10 Volts (CH1 to CH8, fixed). Designed to withstand ± 120 V.



Use the following diagram to connect Analog Input Channel 1.



*WinDaq/Unlock required to record more than four total channels when using WinDaq software.

Digital Ports

The DI-1110 contains 7 general-purpose digital ports.* Each digital port can be configured as a digital input or used as a switch to control an external load (up to 25 V and 100 mA). Many of the ports also provide specific functionality in WINDAQ or a third-party program.

Evt/D0 is for WINDAQ Remote Events. This bit inserts an event marker in your data.


Rcrd/D1 is for WINDAQ Remote Storage. This bit can be programmed to begin recording data.

Rate/D2 is for Rate measurements: 10Hz to 50kHz.


Cnt/D3 is for Counter/Timer measurements up to 65,536.

D4 to D6 are general-purpose digital inputs.

Equivalent Digital I/O Circuit:




Valid remote record and event signals are switch closures or discrete levels with a maximum input of 25 V and a TTL level threshold.



*WinDaq/Unlock required to record more than four total channels when using WinDaq software.


WINDAQ Remote Events (Evt/D0)

To use a switch closure or TTL signal to record WINDAQ Event Markers, connect signal leads to the appropriate Remote Control Event terminals on the DI-1110 as shown below.




Once the switch closure or TTL signal is connected, activate Remote Events through WINDAQ Acquisition Software. Events may be automatically placed on the rising or falling edge of the trigger signal. Use the menu command **Options > Remote Events +** to set WINDAQ to place event markers on low-to-high transitions of the Event input. Use the menu command **Options > Remote Events -** to set WINDAQ to place event markers on high-to-low transitions of the Event input.

Event markers may also be placed in your data file manually by pressing the push button on the DI-1110 Instrument. You must enable Remote Events in WINDAQ to use the button (use the menu command **Options > Remote Events +** or **Options > Remote Events -**).



An example event marker in a WINDAQ data file is shown below.


Event Marker*



***Please Note:** Event Markers do not display in the real-time WINDAQ acquisition software - they only display in the WINDAQ playback software (WWB).

WINDAQ Remote Storage (Rcrd/D1)

To use a switch closure or TTL signal to begin recording data remotely, connect signal leads to the appropriate Remote Control Record terminals on the DI-1110 as shown below.




Once the switch closure or TTL signal is connected, activate Remote Storage (Record) through WINDAQ Acquisition Software. Storage to Disk may be automatically placed on the rising or falling edge of the trigger signal. Use the menu command **Options > Remote Storage 1** to set WINDAQ to begin recording on low-to-high transitions of the Record input. Use the menu command **Options > Remote Storage 0** to set WINDAQ to begin recording on high-to-low transitions of the Record input.


WINDAQ Rate (Rate/D2)

Enable channel 10 to record Rate, or the number of falling-edge transitions per unit of time that are applied to this input. Click on **Edit > Channels** in the WINDAQ Acquisition menu to open the Channel Selection grid. Channel 10 is

the designated Rate channel. Click on the Channel 10 channel box to enable/disable Rates. The Channel 10 channel box will display an “R” when enabled.




Connect any TTL pulse stream (25 VDC max) to the D2 Rate channel on the DI-1110.



Select Channel 10 in the channel display, then select **Edit > Channel Settings** in the menu to specify a full scale range for the Rate channel. Ranges of 10, 20, 50, 100, 200, 500, 1000, 2000, 5000, 10000, 20000, and 50000 Hz are available. Choose a range that comes closest to your expected full scale rate or frequency. For example, if you need to measure the output of a flow meter that can measure a maximum flow rate of 100 gallons per minute, and the output frequency at that rate is 100 Hz, you would choose the 100 Hz range setting. A range setting of 200 Hz full scale sac-

rifices half of the instrument's resolution at 200 gallons per minute, and a range of 50 Hz allows measurements to only 50 gallons per minute full scale.




Check the "Cycles/min" box to display and select frequencies reported in cycles per minute instead of cycles per second (the measurement interval remains the same). Tachometer measurements in units of RPM (revolutions per minute) is just one example that benefits from selecting this option. For example, if the 100 Hz range setting is selected and "Cycles/min" is checked, the full scale range is actually 6000 cycles per minute.

Please Note: To measure the maximum rate, which is defined as 2 times the Maximum Sample Rate/Channel, the current values of Maximum Sample Rate/Channel divided by Sample Rate per Channel MUST be an integer.

WINDAQ Counter (Cnt/D3)

Enable channel 11 to record Counts, or the number of falling-edge transitions that are applied to this input. The count may be reset via WINDAQ software or under program control as necessary. Click on **Edit > Channels** in the WINDAQ

Acquisition menu to open the Channel Selection grid. Channel 11 is the designated Count channel. Click on the Channel 11 channel box to enable/disable Counts. The Channel 11 channel box will display a “C” when enabled.




The counter channel accumulates counts over time whether recording or in standby mode as soon as the Counter channel is enabled. The *accumulated* values will be recorded to your data file unless you reset the counts to zero. The maximum count value is 65,535 before the counter resets to zero automatically.

Use the Edit > **Reset Count** command in WINDAQ Acquisition software to reset counts immediately to zero. This feature is available in both standby and record modes.

Use the Edit > Preferences > **Reset Count on New File Record** in WINDAQ Acquisition software to reset the count at the start of a new file or when using the Edit > Preferences > Record Next File on Full or Open Next File on Full feature to reset counts to zero every time a new file is started.


Use the Edit > Preferences > **Reset Count on Manual Record** in WINDAQ Acquisition software to reset counts to zero every time you begin or resume recording a data file using the File > Record command (F4).

Connect any TTL pulse stream (25 VDC max) to the D3 Count channel on the DI-1110.



General Purpose Digital Inputs


Enable Channel 9 for general-purpose digital input functions. Click on **Edit > Channels** in the WINDAQ Acquisition menu to open the Channel Selection grid. Channel 9 is the designated Digital Input channel. Click on the Channel 9 channel box to enable/disable the digital inputs. The Channel 9 channel box will display an “I” when enabled.



Channel 9 records and displays all the digital inputs, even the state of the Rate and Count inputs if those channels are enabled. With Channel 9 selected in the display window click **Scaling > Digital Plot** to show a digital display and make the data more meaningful on screen.


General Purpose Digital Outputs

Take care when configuring the load to be switched to ensure that the digital port is not damaged:




4-20mA Current Loop Measurements


Use the following diagram for 4-20mA current loop measurement connections.



The shunt resistor should be placed on the low side of the circuit as shown below:



Set the engineering units as desired and define upper/lower levels in WINDAQ as 1V = 4mA for the low value and 5V = 20mA for the high value. For example, when using WINDAQ Acquisition software, in the EU Settings dialog box:



Enter the following values:

	Volt	EU	EU Tag
Upper Level	5	20	mA
Lower Level	1	4	

Visit our website at <http://www.dataq.com/blog/data-acquisition/4-20-ma-current-loop-measurements/> to address all popular 4-20mA configurations.

You can also associate these values to a physical measurement such as pressure, load, flow, torque, etc. Read the Help files for more information regarding Engineering Units Settings.

LED Indicator

The DI-1110 provides three LEDs for instrument status and notification.

Power: Green LED indicates power is applied via the USB cable.


Active: Indicates the device is in use either by WINDAQ Acquisition Software or a custom user-developed program.

Remote: Red LED indicates when the Event Button is pushed or the Event terminals are connected via a relay contact or digital input.

5. Unlock WinDaq

The DI-1110 will record up to four channels using WinDaq/Lite software. An unlock code is required to record more than 4 channels. Go to <https://www.dataq.com/products/di-1110/> to purchase the unlock code (click on the Accessories tab) or call 330-668-1444. Once purchased, you will be given a Key code to enter into WinDaq.


1. Start WinDaq Acquisition software.
2. Click the menu item **Help > Unlock WinDaq**.



3. Enter the Key in the appropriate dialog boxes.
4. Click **OK**.

You can now record all the channels available on your device.

6. Dimensional Drawing





DATAQ Instruments, Inc.
241 Springside Drive
Akron, Ohio 44333
Telephone: 330-668-1444
Fax: 330-666-5434
E-mail: support@dataq.com

Direct Product Links
(click on text to jump to page)
[Data Acquisition](#) | [Data Logger](#)