

Four Easy Steps to Wi-Fi Data Acquisition

By Shawn MacDonald

DATAQ Instruments

Wireless fidelity, also known as Wi-Fi, is a term used to describe wireless networking technology. Instead of using cables to move data through an Ethernet network, Wi-Fi uses radio waves, eliminating the need for a physical connection to send and receive data. This allows multiple users to connect to the internet, a local area network or any other Wi-Fi enabled product without the limitations of being tethered to a CAT-5 Ethernet cable.

The IEEE (Institute of Electrical and Electronic Engineers) has set three standards in the area of wireless technology; 802.11a, 802.11b and 802.11g (with a fourth 802.11n high speed standard pending). These standards relate primarily to speed (data transfer rates), frequency and range.

Wireless Standard	Wireless B	Wireless G (802.11 G)	Wireless A/G	Wireless N
Performance Advantage 	N/A	Up to 5 Times Faster Than Wireless B	Uncrowded 5GHz Band	Up to 12X Faster than Wireless G. Range up to 4X farther
Cost 			 	   
Frequency 2.4 GHz	2.4Ghz	2.4Ghz	2.4Ghz & 5Ghz	2.4Ghz
Range 	Typically Up To 150ft	Up to 150 ft	Up to 150 ft (Wireless G) Up to 150 ft (Wireless G)	Up to 4X farther than Wireless G
Public Hot Spots 	More Popular Standards for hotspots	Yes	Yes in a Wireless-G Mode Growing use in Wireless-A	Yes
Compatibility 	802.11b & 802.11g	802.11b & 802.11g	802.11a, 802.11b & 802.11g	802.11b & 802.11g Based on MiMo Technology
Key Benefits  	Legacy Standard	Fast Speed	Fast Speed with less interference from other Wireless LANs. Works with all wireless standards	Streams High Definition Video

Chart courtesy of Linksys


By now you're probably wondering what this has to do with data acquisition. Although Wi-Fi devices are used primarily as wireless Internet or LAN access points, their applications are far ranging. A Wi-Fi network can be used to access a DATAQ Instruments' Ethernet device from up to 150 feet away! Wi-Fi capability allows you to monitor your WinDaq data from virtually anywhere in the building without the bother of running back and fourth or laying cable, all for around \$150.



All you need to begin wireless data acquisition. **A.** Wireless Router; **B.** Wireless Access point; and **C.** DATAQ Instruments DI-730EN (or any DATAQ Instruments Ethernet device). We used wireless products manufactured by D-Link for our test. Other leading Wi-Fi manufacturers include include Linksys and Netgear.

Setting Up Your Wireless Data Acquisition Network

For our test we used a DATAQ Instruments DI-730EN along with a D-link 802.11g DI-634M Wireless Broadband Router and a D-link DWL-2100AP Wireless Access Point.



The router was connected to a Dell Dimension desktop computer with a 2.53GHz Intel Celeron D processor. Four tests were conducted. The wireless access point was first placed approx. 10 feet away, in the same room as the router and then 60 feet away, in a 3 second room (transmitting

through two walls constructed of metal studs and drywall). The maximum record to disk rate without gaps, using WinDaq software, was 170,000 samples per second at 10 feet and 120,000 samples per second at 60 feet (at standard 802.11g, 54Mbps transfer rates). Using D-Link's Super G Turbo technology to boost communication speeds even further (108Mbps), we were able to achieve gap free record to disk rates as high as 186,046 samples per second at 10 feet and 155,000 samples per second at 60 feet.

	10 feet	60 feet
Standard G	170,000 S/s	120,000 S/s
Super G Turbo Technology	186,046 S/s	155,000 S/s
Gap free record to disk rates at standard 802.11g and Super G Turbo communication speeds.		

Setup was a simple, four step process:

1. Connect port one of the D-Link Wireless Router to the Ethernet card of your computer using a CAT-5 patch cable.
2. Connect the D-Link Bridge to the DATAQ Instruments DI-730EN using a CAT-5 patch cable.
3. Run the D-Link configuration utility and install software for the wireless router.
4. Power up the DI-730EN and run WinDaq software as usual.

That's all there is to it! In a matter of minutes you can be up and running at sample rates as high as 186,000 samples per second with little or no help from your network administrator. So take a few minutes out of your day, set it up, and enjoy the convenience of wireless data acquisition.

Real Life Application—The University of Akron

To further illustrate the capabilities of wireless data acquisition, we'll take a look at one such wireless network being used by The University of Akron in Akron, Ohio. As part of The Society of Automotive Engineers, a group of engineering students at The University of Akron take part in a project that requires them to design and fabricate small formulastyle cars. These cars are then

entered into a national competition against designs from other schools and judged based upon design and performance.



One of the cars designed and built by engineering students at The University of Akron.

To optimize the performance of their cars, students at The University of Akron use wireless data acquisition technology to monitor on-board data while the cars are on the track. For example, one such measurement is shock absorber travel, measured using linear potentiometers. This data is collected using a DATAQ Instruments DI-720EN and is then transmitted via an SMC Networks wireless access point to a laptop computer. The data is then reviewed and analyzed using WinDaq software. The students are able to receive and record their data (at a sample rate of 100 cycles per second x 5 channels) from up to 1000 feet away in the open, outdoor environment with the aid of a parabolic Wi-Fi dish antenna. Virtually any measurement, from engine temperature to fuel level, can be received and recorded in real time.



Rear view of a DATAQ Instruments DI-720EN mounted inside one of the cars (left) and the SMC wireless access point mounted atop the engine (right).

The data collected using wireless data acquisition technology can prove invaluable to the engineering students when it comes to making adjustments to improve the performance of their cars. Rather than the driver sensing a problem and making a hit or miss adjustment to correct it, precise adjustments can be made based on the real-time track data. This is just one example of the cost effective power and convenience of wireless data acquisition.